



# Anthem One PW-UVC Base System

Model A-PW-UVC-001  
Operating Safety Instructions

## ► Misuse and Related Statements

This product should only be operated by an individual who has been trained and read all safety precautions and operators manual.

## APPLICATION DIRECTIONS

### ► Worker Protection Standard (WPS)

**Personal Protective Equipment (PPE) is REQUIRED to be used while operating the device.** UV rated goggles or UV rated face mask shall be worn at all times. Cover exposed skin using gloves and a long sleeve shirt when using the device. Always put on PPE gear first before turning on the UV-C unit.

The device should not be operated if others are in the room and not wearing protective gear. If operating the device in a room with other occupants, operator must ensure they are all wearing protective gear. If two workers are operating devices in the same area, both should 1) wear protective gear 2) space apart (10 feet apart) and travel in the same direction together while maintain spacing at all times while operating any UV-C units in the space.

Keep the key in off position, and remove from the UV-C unit when done operating and during storage.

### ► Instructions for Use

After putting on appropriate safety gear, take hold of the grip handle and face the unit towards the surface intended to disinfect and away from your eyes. Once the room is clear of other animals and humans not in protective gear, insert the key and unlock the unit. When ready to begin, turn on the power switch located at the back of the light head near the cord input.

The light head should be used 2” from a target surface. A swiping motion is to be used at a rate of 1 ft/sec. Continue to disinfect all surfaces and then turn off the unit.

When done with the unit and ready to store, be sure to use the key to lock the mechanism and return the device to its

storage container. Do not leave the key in the unit unattended.

## **SERVICING**

Refer all servicing to manufacturer. Servicing is required when unit has been damaged in any way, such as when the power cord or plug is damaged, liquid has been spilled, or unit has been exposed to rain or moisture, or does not operate normally.

Do not attempt to open Unit or disassemble it. You run the risk of electric shock, and damage caused by disassembly is not covered by the limited warranty. Opening the device voids the manufacturer warranty. No user-serviceable parts are inside.

For servicing the Model A-PW-UVC-001 you may find a facility near you by referring to [www.anthemone.com](http://www.anthemone.com) or 602- 837-4800 to contact manufacturer. Warranty is for one year from date of purchase.

## **CLEANING**

Insure unit is powered off and locked before cleaning. Clean only with a dry cloth.

Do not block any ventilation openings.

## **IMPORTANT: READ BEFORE USE**

Read the entire **Directions for Use, Conditions, Disclaimer of Warranties and Limitations of Liability** before using this product.

By using this product, user or buyer accepts the following Conditions, Disclaimer of Warranties and Limitations of Liability.

**CONDITIONS:** The directions for use of this product are believed to be adequate and must be followed carefully. However, it is impossible to eliminate all the risks associated with the use of this product. Lack of performance, inefficacy or other unintended consequences may result because of such factors as weather conditions, presence of other materials, or the manner of use or application, all of which are beyond the control of Anthem One, Inc (“Anthem”). All such risk shall be assumed by the user or buyer.

**DISCLAIMER OF WARRANTIES:** TO THE EXTENT CONSISTENT WITH APPLICABLE LAW, ANTHEM MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE, THAT EXTEND BEYOND THE STATEMENTS MADE ON THIS LABEL. NO AGENT OF ANTHEM IS AUTHORIZED TO MAKE ANY WARRANTIES BEYOND THOSE CONTAINED HEREIN OR TO MODIFY THE WARRANTIES CONTAINED HEREIN. TO THE EXTENT CONSISTENT WITH APPLICABLE LAW, ANTHEM, THE MANUFACTURER, OR THE SELLER SHALL NOT BE LIABLE WHATSOEVER FOR ANY CONSEQUENTIAL, SPECIAL, OR INCIDENTAL DAMAGES RESULTING FROM THE USE, HANDLING, APPLICATION, STORAGE OR DISPOSAL OF THIS PRODUCT OR FOR DAMAGES IN THE NATURE OF PENALTIES, AND THE BUYER AND THE USER WAIVE ANY RIGHT THAT THEY MAY HAVE TO SUCH DAMAGES.

**LIMITATIONS OF LIABILITY:** TO THE EXTENT CONSISTENT WITH APPLICABLE LAW, THE EXCLUSIVE REMEDY OF THE USER OR BUYER FOR ANY AND ALL LOSSES, INJURIES OR DAMAGES RESULTING FROM THE USE OR HANDLING OF THIS PRODUCT, WHETHER IN CONTRACT, WARRANTY, TORT, NEGLIGENCE, STRICT LIABILITY OR OTHERWISE SHALL NOT EXCEED THE PURCHASE PRICE PAID, OR AT ANTHEMS' ELECTION, THE REPLACEMENT OF THE PRODUCT.


**Storage and Disposal**

This unit is not restricted and contains no hazardous chemicals. Please dispose of following local requirements for electronics disposal.

► **Safety Manual and Instructions**

The Anthem One UV-C should be stored in its original case along with the operator's manual and safety instructions. If you need a replacement manual or to watch a video on safety instructions, please contact us at: [www.anthemone.com](http://www.anthemone.com) 602-837-4800 [info@anthemone.com](mailto:info@anthemone.com)

UVC radiation can cause burns (of the skin) and eye injuries (photokeratitis). Avoid direct skin exposure to UVC radiation and never look directly into a UVC light source, even briefly. If customers identify a problem with a UVC lamp, they can report it to the manufacturer.

<b>⚠ CAUTION</b>		These directions available online at
<b>UV radiation hazard.</b> Use only with shielding in place. Protect eyes & skin from exposure to UV light.		